



## **REFRIGERATION EQUIPMENT HIRE INSTRUCTIONS & SAFETY**

Thanks for choosing McHugh Hire, please take a minute to read the applicable instructions relating to the equipment you have hired.

We're sorry if some of the info sounds like common sense, but we need to cover all the bases. We've tried to translate the instructions for our equipment into a language that people can understand, if any part of it doesn't make any sense, please let us know and we'll fix it.

Please make sure you have fully read the instructions and all terms and conditions and product info at [www.mchughhire.com](http://www.mchughhire.com) before using any of our equipment to avoid extra cleaning, hire or damage charges.

**All of our equipment and equipment's packaging must be returned in the same condition as it was delivered or the hirer will be charged for replacement. All equipment and packaging must be properly cleaned before return unless otherwise stated or paid for.**

**All equipment is for adult use only unless otherwise stated.**

**DO NOT LEAVE OUR EQUIPMENT OUT IN THE RAIN.**

When you have finished with your equipment please make sure everything is wiped down and cleaned in the same condition you received it. If your equipment is returned un-clean you will be charged for cleaning.

For equipment lost or damaged by misuse you will be charged for replacement or repair.

It is your responsibility to ensure all power leads will not be a trip hazard, we have safety cable covers for hire if required. Please also make sure your leads are clear of water, heat and any other hazardous source. If you have hired RCD safety switches or blocks, please test the devices by pressing the trip button(s) before using each day.

For any equipment that comes with spare parts/batteries/bulbs etc:

Do NOT discard the original/dead parts/batteries/bulbs. They must be marked "dead" and returned with the equipment for our post hire testing. Failure to do so will incur a replacement charge on return. Missing AA, 23A, AAA batteries will be charged at \$2.50 each. All other missing parts will be charged at RRP.

**All equipment must be packed away, at loading area, ready for our drivers to pickup.**

You are responsible for using our equipment safely, especially equipment that produce heat. Please use common sense and keep children supervised near all McHugh Hire equipment.

Please note many of our items contain GPS tracking units to prevent theft and to recover stolen equipment. This includes all of our expensive equipment and random lower cost items. If you are using the equipment in a high security area, please check that these transmitters won't be a problem on site.

---

### **Mobile coolroom & trailer hire:**

Plug the mobile coolroom into regular 240 volt 10 amp power and it will start. Each machine must be run on it's own power point. Do not run any other devices from the same mains supply.

Our coolrooms are pre-set to 1.9°C and fluctuate between 0°C and 4°C approx. during their regular cycling. If you require a different temperature (florists etc) please let us know prior to arrival.

If the overload safety switches trip for any reason, please call us immediately on 6162 1662 and we will assist you. If you are using one of our petrol generators, please make sure you also read the applicable instructions to the generator units.

The interior and exterior of the coolroom must be cleaned before return to avoid a cleaning charge. All shelving, draw bar locks, matting, extension cords and other provided equipment must be returned to avoid extra charges.

Tips: if you are cooling large quantities of drinks/food etc that are warm, leave space between your stock (especially cartons) for faster chilling. The less cold air that can get between your stock the longer it will take to chill. If you need to chill large quantities of product you may need to hire your coolroom earlier so you can get it chilled on time. If you have pre-chilled stock you won't have to wait.

When cooling down your unit, please do not open the door. You must first let the coolroom get down to temperature and de-humidify or the coolroom blower will freeze up. This will take a while to defrost and operate correctly again.

If you are towing the trailer yourself, please let us know before collection if your vehicles electrical trailer plug is flat, small round or big round. If you are unsure about your vehicles ability to tow the trailer, please check with us first. For dual axle trailers please also ask us about using the trailers built in inertia brakes, there is different requirements depending on the load and vehicle size.

### **Chest freezer hire:**

Let the freezer settle for 1 hour before operation. Then plug the chest freezer into regular 240 volt 10 amp power and it will start.

The variable thermostat control range (1-5) is from -7°C to -25°C. Most people will operate it on level 4, we have measured this to be around -20°C. For critical stock we recommend using your own temperature checks to avoid spoilage.

### **Display fridge hire:**

Plug the mobile coolroom into regular 240 volt 10 amp power and it will start. Each machine must be run on it's own power point. Do not run any other devices from the same mains supply.

Our display fridges are pre-set to 0°C (best for drinks) and fluctuate between -1°C and 2°C approx. during their regular cycling. If you require a different temperature (for food etc.) please let us know prior to arrival.

Please be very careful when moving these fridges to avoid injury and damage.

---

**We wish you all the best and thank you for choosing McHugh Hire for your hire needs!**

If you have any great photo's of our equipment in action we'd love you to share them with the McHugh Hire community via our Facebook page <https://fb.me/McHughHireShop> or email [bookings@mchughhire.com](mailto:bookings@mchughhire.com)

If you have any queries please call us on 6162 1662.



